

www.cersanit.com

NANO

PL

instrukcja montażu

LT

montavimo instrukcija

LV

montāžas instrukcija

RU

инструкция по монтажу

UK

інструкція по монтажу

SK

návod na montáž

CZ

návod na montáž

DE

anleitung

EN

instructions for assembly

ET






paigaldusjuhend





HU

szereelési útmutató


RO

instrucțiuni de montaj







1






2




3








6




7




x4

90°



8




9




10



11







12



13

x2





Cersanit S.A.
Al. Solidarności 36, 25-323 Kielce
tel. 41 / 315 80 04, fax 41 / 315 80 06
www.cersanit.com